

BOOSTER MODULE & DRIVE SPARE KIT IH1800



No	PARTS LIST	SIZE	ITEM NO	EA
1	DEEP GROOVE BALL BEARING		GR-I8-001	4
2	IH BOOSTER OIL SEAL		GR-I8-002	8
3	O-Ring (VITON)		GR-I8-003	8
	O-Ring (VITON)		GR-I8-004	4
	O-Ring (VITON)		GR-I8-005	8
	O-Ring (VITON)		GR-I8-006	6
	O-Ring (VITON)		GR-I8-007	1
	O-Ring (VITON)		GR-I8-008	2
	O-Ring (VITON)		GR-I8-009	2
	O-Ring (VITON)		GR-I8-010	4
	O-Ring (VITON)		GR-I8-011	1
	O-Ring (VITON)		GR-I8-012	1
	O-Ring (VITON)		GR-I8-013	2
	O-Ring (VITON)		GR-I8-014	4
	O-Ring (VITON)		GR-I8-015	1
	O-Ring (VITON)		GR-I8-016	1
	O-Ring (VITON)		GR-I8-017	2
	O-Ring (VITON)		GR-I8-018	4
	O-Ring (VITON)		GR-I8-019	1